

HOME DECORATORS C O L L E C T I O N


BF-25215 MARTHA STEWART LIVING KIDS CRAFT DRYING RACK 31"Hx33"Wx20"D

INV#19045

ASSEMBLY INSTRUCTIONS













Made In China


THIS ITEM MUST BE ASSEMBLED BY AN ADULT




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.


PARTS LIST		
A  TOP PANEL-1PC	B  LEFT SIDE PANEL-1PC	C  RIGHT SIDE PANEL-1PC
D  BOTTOM PANEL-1PC	E  BACK PANEL-1PC	F  ACROSS FRAME-1PC
G  ADORNING PANEL-1PC	H  ACROSS PANEL-1PC	I  PALLETS-3PCS
J  TRAY-1PC	K  DRAWER SUPPORT PANELS-2PCS	L  SMALL DRAWER PANEL FRONT-1PC

M

LEFT SMALL
DRAWER PANEL SIDE-1PC

N


RIGHT SMALL
DRAWER PANEL SIDE-1PC

O

SMALL
DRAWER PANEL BACK-1PC

P


DRAWER PANEL BOTTOMS-2PCS

Q


SMALL
DRAWER STAND PANELS-2PCS

R


SMALL
DRAWER STAND PANELS-2PCS

S


SMALL
DRAWER ACROSS PANEL-1PC

T


LARGE
DRAWER PANEL FRONT-1PC

U


LEFT LARGE
DRAWER PANEL SIDE-1PC

V

RIGHT LARGE
DRAWER PANEL SIDE-1PC

W


LARGE
DRAWER PANEL BACK-1PC

X

LARGE
DRAWER STAND PANELS-2PCS

Y


LARGE
DRAWER STAND PANELS-2PCS

Z

LARGE
DRAWER ACROSS PANEL-1PC

A1

CAM-TOOL-1PC

B1
















CAM-BOLTS-17PCS

C1

CAM-LOCKS-17PCS



D1

KNOB-4PCS

E1 8mm × 5/8"  SCREWS-4PCS	F1  FEET-4PCS	G1  DOWELS-2PCS
H1  OUTER SLIDES-4PCS	I1  INNER SLIDES-4PCS	J1 6mm × 1/2"  SCREWS-24PCS
K1 8mm × 1"  SCREWS-3PCS	L1 6mm × 1"  SCREWS-24PCS	M1 11mm × 1"  BOLTS-6PCS
N1  ALLEN WRENCH-1PC	O1 7mm × 7/8"  SCREWS-4PCS	P1  HOOKS-4PCS
Q1  PLASTIC BELTS-2PCS	R1  GECKOS-4PCS	S1 6mm × 3/4"  SCREWS-4PCS




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: ● UPON OPENING THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: ● THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1). ASSEMBLE THE OUTER SLIDES (H1).

- ATTACH THE OUTER SLIDES (H1) TO LEFT SIDE PANEL (B) USING 6 SCREWS (J1).




2). ASSEMBLE THE OUTER SLIDES (H1).

- ATTACH THE OUTER SLIDES (H1) TO RIGHT SIDE PANEL (C) USING 6 SCREWS (J1).




3). ASSEMBLE THE BACK PANEL (E).

- ROTATE 2 CAM-BOLTS (B1) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE CAM-BOLTS (B1) INTO THE HOLES IN THE BACK PANEL (B) AND ATTACH USING 2 CAM-LOCKS (C1).




4). ASSEMBLE THE ACROSS FRAME (F).

- ATTACH THE ACROSS FRAME (F) TO LEFT SIDE PANEL (B) USING 2 BOLTS (M1).




5). ASSEMBLE THE ACROSS FRAME(F).

- ROTATE 2 BOLTS(M1) INTO THE HOLES IN THE ACROSS FRAME(F).




6). ASSEMBLE THE ACROSS PANEL(H).

- ROTATE 1 CAM-BOLT(B1) AND INSERT 1 DOWEL(G1) INTO THE HOLES IN THE LEFT SIDE PANEL(B).
- PLACE CAM-BOLTS(B1) INTO THE HOLES IN THE ACROSS PANEL(H) AND ATTACH USING 1 CAM-LOCK(C1).




7). ASSEMBLE THE BOTTOM PANEL (D).

- ROTATE 2 CAM-BOLTS (B1) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE CAM-BOLTS (B1) INTO THE HOLES IN THE BOTTOM PANEL (D) AND ATTACH USING 2 CAM-LOCKS (C1).




8). ASSEMBLE THE RIGHT SIDE PANEL (C).

- ROTATE 5 CAM-BOLTS (B1) AND INSERT 1 DOWEL (G1) INTO THE HOLES IN THE RIGHT SIDE PANEL (C).
- PLACE CAM-BOLTS (B1) INTO THE HOLES IN THE PANEL (D/E/H/F) AND ATTACH USING 5 CAM-LOCKS (C1).




9). ASSEMBLE THE ACROSS FRAME (F).

- ROTATE 2 BOLTS(M1) INTO THE HOLES IN THE ACROSS FRAME (F).




10). ASSEMBLE THE FEET (F1).

- ROTATE 4 FEET (F1) INTO THE HOLES IN THE SIDE PANEL (B/C).




11). ASSEMBLE THE ADORNING PANEL (G).

- ATTACH THE ADORNING PANEL (G) TO TOP PANEL (A) USING 3 SCREWS (K1).



12). ASSEMBLE THE TOP PANEL (A).


- ROTATE 7 CAM-BOLTS (B1) INTO THE HOLES IN THE TOP PANEL (A).
- PLACE CAM-BOLTS (B1) INTO THE HOLES IN THE PANEL (B/C/E) AND ATTACH USING 7 CAM-LOCKS (C1).



13). ASSEMBLE THE SMALL DRAWER.


- ATTACH SMALL DRAWER PANEL SIDE(M/N) USING 4 SCREWS(L1).
- ATTACH 2 KNOBS(D1) TO SMALL DRAWER PANEL FRONT(L) USING 2 SCREWS(E1).
- INSERT THE DRAWER PANEL BOTTOM(P) INTO THE SLOTS IN THE SMALL DRAWER PANEL SIDE(M/N).
- ATTACH SMALL DRAWER PANEL BACK(O) BETWEEN SMALL LEFT DRAWER PANEL SIDE(M) AND SMALL RIGHT DRAWER PANEL SIDE(N) USING 4 SCREWS(L1).
- ATTACH THE DRAWER SUPPORT PANEL(K) TO DRAWER PANEL BOTTOM(P) USING 4 SCREWS(L1).
- INSERT PANEL(Q/R/S) INTO THE SLOTS IN THE SMALL DRAWER.

Arrow faces drawer front



14). ASSEMBLE THE INNER SLIDES(I1).


- ATTACH THE 2 INNER SLIDES(I1) TO SMALL DRAWER PANEL SIDE(M/N) USING 6 SCREWS(J1).



15). ASSEMBLE THE LARGE DRAWER.


- ATTACH LARGE DRAWER PANEL SIDE(U/V) USING 4 SCREWS(L1).
- ATTACH 2 KNOBS(D1) TO LARGE DRAWER PANEL FRONT(T) USING 2 SCREWS(E1).
- INSERT THE DRAWER PANEL BOTTOM(P) INTO THE SLOTS IN THE LARGE DRAWER PANEL SIDE(U/V).
- ATTACH LARGE DRAWER PANEL BACK(W) BETWEEN LARGE LEFT DRAWER PANEL SIDE(U) AND LARGE RIGHT DRAWER PANEL SIDE(V) USING 4 SCREWS(L1).
- ATTACH THE DRAWER SUPPORT PANEL(K) TO DRAWER PANEL BOTTOM(P) USING 4 SCREWS(L1).
- INSERT PANEL(X/Y/Z) INTO THE SLOTS IN THE LARGE DRAWER.

Arrow faces drawer front




16). ASSEMBLE THE INNER SLIDES(I1).

- ATTACH THE 2 INNER SLIDES(I1) TO LARGE DRAWER PANEL SIDE(U/V) USING 6 SCREWS(J1).



17). ASSEMBLE THE DRAWERS.

- INSERT 2 DRAWERS INTO THE SLIDERS.




18). ASSEMBLE THE PALLETS(I) AND TRAY(J).

- INSERT THE PALLETS(I) AND TRAY(J) INTO THE CABINET.
BE SURE TO LINE BOTTOM DRIP TRAY(J) WITH PAPER.



Warning

The anti-tip hardware must be used as part of assembly!



19). ASSEMBLE THE HOOKS (P1).

- ATTACH THE HOOKS (P1) TO TOP PANEL (A) USING 4 SCREWS (S1).



20). ASSEMBLE THE ANTI-TIP HARDWARE.

- DRILL 4 HOLES INTO THE WALL, PLEASE REFER TO THE REAR TOP PANEN'S HOLE DISTANCE AND HEIGHT.
- PUT 4 GECKOS(R1) INTO THE HOLES IN THE WALL, AND ROTATE 4 SCREWS(O1) INTO THE GECKOS(R1).
- CONNECT THE TWO HOOKS(P1) WITH A PLASTIC BELT(Q1).